



[FAQs](#) > [X-TERRA](#) > [X-TERRA INTREPID](#) > [X-TERRA INTREPID - Quick Help](#)

X-TERRA INTREPID - Quick Help

Sarah Schernthanner - 2026-02-27 - [X-TERRA INTREPID](#)

Quick Help

1. Turn On

Press the Power button.
Wait 5 seconds for calibration.

2. Start Detecting

Sweep the coil side-to-side, close and parallel to the ground.
The coil detects only while moving.

3. Identify Targets

A beep + Target ID (0-99) appears on screen.
Depth Gauge shows approximate depth.

4. Use Pinpoint

Hold Pinpoint to locate center of the target.
Sweep slowly and listen for the strongest signal.

5. Adjust Sensitivity

Press + / - → 5 sensitivity levels.
Choose the highest stable setting.

6. Search Modes

Long-press Volume to switch: ALL METAL (default) NO IRON (filters iron)

7. Batteries

Uses 2× 9V, replace both at once.