



[FAQs](#) > [PRO-FIND](#) > [PRO-FIND 35](#) > [PRO-FIND 35 - Quick Help](#)

PRO-FIND 35 - Quick Help

Sarah Schernthanner - 2026-02-26 - [PRO-FIND 35](#)

Quick Help

1. Set Up

Insert a 9V PP3 battery (included).
Ensure the battery cap O-ring is clean to maintain waterproof sealing.
Screw the cap on firmly.

2. Power On

Press and hold the Power button.
The LED flashlight turns on briefly and the unit initializes.

3. Start Pinpointing

Move the tip slowly over the target area.
Audio tones and vibrations intensify as you approach the target.
A constant tone = very close.

4. Choose Sensitivity

Select from 5 sensitivity levels using the + / - buttons.
Higher = deeper/smaller targets. Lower = calmer in mineralized zones.

5. Ferrous Tone ID

Provides dual audio tones:

High tone = valuable (non-ferrous)
Low tone = iron (junk)