



[FAQs](#) > [VANQUISH](#) > [VANQUISH 440](#) > [VANQUISH 440 - Quick Help](#)

VANQUISH 440 - Quick Help

Sarah Schernthanner - 2026-03-06 - [VANQUISH 440](#)

Quick Help

1. Assembly

Connect shaft parts.
Attach search coil and secure bolt.
Wrap coil cable along the shaft.
Insert 4× AA batteries.

2. Quick Start

Press Power.
Wait 5 seconds for automatic noise cancel.
Start detecting.

3. Search Modes

Coin - Ignores trash - ideal for parks & beaches.
Relic - Best depth for fields & forests.
Jewellery - Balanced mode for valuable finds.
Custom - Save your own discrimination pattern.

4. Key Controls

Power
Volume
All-Metal
Pinpoint
Sensitivity
Accept/Reject
Mode Select

5. Display

Battery
Volume
Sensitivity
Target-ID (-9 to 40)
Depth Gauge
Mode
Discrimination Segments