



[FAQs](#) > [X-TERRA](#) > [X-TERRA INTREPID](#) > [X-TERRA INTREPID - Quick Help](#)

# X-TERRA INTREPID - Quick Help

Sarah Schernthanner - 2026-02-27 - [X-TERRA INTREPID](#)

## Quick Help

### 1. Turn On

Press the Power button.  
Wait 5 seconds for calibration.

### 2. Start Detecting

Sweep the coil side-to-side, close and parallel to the ground.  
The coil detects only while moving.

### 3. Identify Targets

A beep + Target ID (0-99) appears on screen.  
Depth Gauge shows approximate depth.

### 4. Use Pinpoint

Hold Pinpoint to locate center of the target.  
Sweep slowly and listen for the strongest signal.

### 5. Adjust Sensitivity

Press + / - → 5 sensitivity levels.  
Choose the highest stable setting.

### 6. Search Modes

Long-press Volume to switch: ALL METAL (default) NO IRON (filters iron)

### 7. Batteries

Uses 2× 9V, replace both at once.