



[FAQs](#) > [X-TERRA](#) > [X-TERRA PRO](#) > [X-TERRA PRO - Quick Help](#)

X-TERRA PRO - Quick Help

Sarah Schernthanner - 2026-02-27 - [X-TERRA PRO](#)

Quick Help

1. Turn On

Press Power

Wait 5 seconds for startup calibration [[PRO_Gettin...edGuide_EN](#) | [PDF](#)]

2. Select Search Mode Choose between:

Park (general detecting, high trash)

Field (historic fields, coins & relics)

Beach (dry/wet sand, surf, underwater) [[PRO_Gettin...edGuide_EN](#) | [PDF](#)]

3. Noise Cancel

In Settings, choose Noise Cancel Start Auto Noise Cancel (approx. 5–8 seconds) [[PRO_Instru...nManual_EN](#) | [PDF](#)]

4. Go Detecting

Sweep coil side-to-side, flat & close to ground

Coil detects only while moving [[PRO_Instru...nManual_EN](#) | [PDF](#)]

5. Sensitivity

Adjust with + / - (1-25) Use the highest stable level [[PRO_Instru...nManual_EN](#) | [PDF](#)]

6. Pinpoint

Press Pinpoint to locate exact target position

Watch signal strength on screen [[PRO_Instru...nManual_EN](#) | [PDF](#)]

7. Battery

Internal Li-Ion, charge 5–6 h via USB

Check battery indicator on display